

**TIKKURILA PROFESSIONAL UNICA ADHESION PRIMER AND VALTTI OPAQUE OVER EXISTING PAINTED FACADES AND WINDOW FRAMES.**

Remove dirt, oil and grease etc, by washing down with TIKKURILA PROFESSIONAL CLEANING AGENT then rinse with clean water and allow to dry thoroughly.

Spot prime exposed nail heads with one coat of Tikkurila Professional Unica Metal Primer to prevent rust spots coming through the paint film as is happening at the moment.

Where the paint has badly failed on the newer timber, all the loose paint must be removed the immediate area should be sanded using 150grit sand paper before priming.

Apply 1 coat of Tikkurila Professional Unica Adhesion Primer to all areas where the existing paint film has been removed, allowing to dry thoroughly before the finish coats are applied.

Apply two full coats of Tikkurila Professional Valtti Opaque, allow at least 2 hours between coats.  
DO NOT THIN.

**Selected Colour:**  
**TBA**

