

IMPORTANT NOTES:

Please note these specifications are for guidance only. Before use please check with Symphony Paints (North West) Ltd to ensure suitability of specification.

Repair procedure must be carried out following erection.

All products must be applied in strict accordance with all relevant technical data sheets and attached general instructions for painting structural steel.

Environmental conditions, temperature, humidity, ventilation must be carefully controlled and or monitored both during application and curing.

All work must be carried out in line with BS 5493/ISO 12944-5 BS 6150 and all other relevant standards.

Regular inspection is recommended and repairs carried out as appropriate. i.e. Mechanical damage etc. This will help prevent premature deterioration.

Regular periodic washing will also help extend the life of the applied paint systems.

Disclaimer:

Aragorn can not accept any responsibility for use of these specifications without prior written approval from an authorised Aragorn employee.

